





# INDEX OF HM-36#




Main Rotor Blade  
HM-036-Z-01



Flybar Paddle  
HM-036-Z-02




Flybar  
HM-036-Z-03



Tail Rod Holder  
HM-036-Z-19



Tail Rotor Blade  
HM-036-Z-20



Stabilizer  
HM-036-Z-21



Canopy  
HM-036-Z-37




Gyro  
HM-036-Z-38




Receiver  
HM-036-Z-39



Flybar Paddle Holder  
HM-036-Z-04



Balance Screw  
HM-036-Z-05



Ball Linkage Set  
HM-036-Z-06



Tail Holder  
HM-036-Z-22




Tail Shaft Set  
HM-036-Z-23



skid Landing  
HM-036-Z-24



Motor  
HM-036-Z-40



Servo  
HM-036-Z-41



Battery  
HM-036-Z-42




Aluminum Ball  
HM-036-Z-07



Main Blade Holder  
HM-036-Z-08




Balance Bar Sleeve  
HM-036-Z-09



Tail Boom  
HM-036-Z-25



Gear Set  
HM-036-Z-26



Tail Servo Rod Shaft  
HM-036-Z-27




Transmitter  
HM-036-Z-43



Charger  
HM-036-Z-44



Crystal Oscillator  
HM-036-Z-45



Ballcrank Set  
HM-036-Z-10



Main Blade  
Transverse Shaft  
HM-036-Z-11



Rotor Head  
HM-036-Z-12




Main Shaft Fixing Set  
HM-036-Z-28



Copper Sleeve  
HM-036-Z-29



Principal Axis  
HM-036-Z-30



Kit Content  
HM-036-Z-46




Optional Accessory  
Brushless Motor  
HM-036-Z-47



Optional Accessory  
Speed Controller  
HM-036-Z-48



Main Shaft Sleeve  
HM-036-Z-13



Inner Rod  
HM-036-Z-14




Swashplate  
HM-036-Z-15



Steering Holder  
HM-036-Z-31



Main Gear  
HM-036-Z-32



Main Frame  
HM-036-Z-33



Optional Accessory  
Carbon Fibre Blade  
HM-036-Z-49




Optional Accessory  
Li-Po Battery  
HM-036-Z-50



U-shape Connector  
HM-036-Z-16




Tail Strut  
HM-036-Z-17




Toothed Synchromesh Belt  
HM-036-Z-18



Tail Servo Holder  
HM-036-Z-34



Bearing Set  
HM-036-Z-35



Screw Set  
HM-036-Z-36